



SuperSystems
incorporated



eFlo 2.0

ELECTRONIC GASFLOW METER

OPERATIONS MANUAL

Super Systems Inc.
7205 Edington Drive
Cincinnati, OH 45249
513-772-0060
Fax: 513-772-9466
www.supersystems.com

Super Systems Inc.

USA Office

Corporate Headquarters:

7205 Edington Drive

Shipping Address:

7245 Edington Drive

Cincinnati, OH 45249

Phone: (513) 772-0060

<http://www.supersystems.com>

Super Systems Europe

Unit E, Tyburn Trading Estate,

Ashold Farm Road, Birmingham

B24 9QG

UNITED KINGDOM

Phone: +44 (0) 121 306 5180

<http://www.supersystemseurope.com>

Super Systems México

Sistemas Superiores Integrales S de RL de CV

Calle 3 Int.: 11.

Zona Ind. Benito Juarez

Querétaro, Qro. Méx.

C.P.: 76120

Phone: +52 (442) 210 2459

<http://www.supersystems.com.mx>

Super Systems China

No. 335 XianXia Road

Room 308

Shanghai, CHINA

200336

Phone: +86 21 5206 5701/2

<http://www.supersystems.com>

Super Systems India Pvt. Ltd.

A-26 Mezzanine Floor, FIEE Complex,








Okhla Indl. Area, Phase - 2

New Delhi, India 110 020

Phone: +91 11 41050097

Table of Contents

Introduction.....	5
Model Numbers.....	5
Safety Information.....	6
Specifications.....	6
Installation Procedure	7
Mechanical Installation	7
Clearance.....	7
Mounting.....	7
Plumbing.....	7
Thread Sealants:.....	7
Connection Tightness:.....	7
Leak Checking	8
Electrical Connections	8
Initial Network Configuration	9
nLocateIP Method	9
Modbus Registers	10
Keypad Operating Procedure.....	11
Keypad Basic Functions	12
View Totalized Flow	12
Reset Totalized Flow	12
Switch between Auto and Manual Modes.....	13
Adjust Flow Rate (Manual Mode Only).....	13
Display Setpoint.....	13
Adjust Setpoint.....	13
Display Alarm	13
Enter Menu	13
Keypad Setup Menu System.....	13
Setup Menu Keypad Functions	14
Exiting the Menu System	16
Menu System Details.....	16
Touchscreen Operating Procedure.....	18
Touchscreen Basic Functions	19
View Totalized Flow	19
Reset Totalized Flow	19

Switch between Auto and Manual Modes.....	19
Adjust Flow Rate (Manual Mode Only).....	20
Adjust Setpoint.....	20
Enter Menu	20
 Process Variable Menu.....	21
 Units Menu.....	21
 Gas Menu	22
 Time Menu	22
 Ethernet Communications Menu.....	23
 Serial Communications Menu	23
 Flow Alarm Menu	24
Maintenance.....	24
Web Interface	24
Using the Web Interface.....	24
Main Screen.....	25
Instrument Information	26
Diagnostics	26
Basic Configuration	27
Instrument Configuration	28
Interface Configuration.....	29
Alarms.....	30
Warranty.....	31
Revision History	32
Appendix 1: Menu Option Tables.....	33
Appendix 2: Verification Procedures.....	34
Calibration Verification.....	34
Sensor Accuracy Verification	34
Appendix 3: Startup Procedures.....	35

Introduction

The **eFlo2.0** instrument is Super Systems Inc.'s latest electronic flow meter. eFlo works by measuring the differential pressure (the difference in pressure of a gas at two points) of a gas flowing through a specially designed opening in the gas flow assembly. Based on properties of the flowed gas, the differential pressure can then be used to calculate the flow rate of the gas.

eFlo 2.0 uses a mathematical curve to calculate the flow of a gas and features built-in diagnostic information, flow rate and pressure alarms, and a flow rate totalizer. The automatic meter can be set to automatic or manual valve control mode. Automatic valve control mode allows the eFlo to use a flow rate or valve position setpoint as a basis for adjusting the valve (and thus the gas flow) using a built-in valve motor. The setpoint can be programmed manually by the user or obtained by the instrument from a 4-20mA analog signal or a digital signal over RS485. Manual valve control mode allows the user to manually set the valve position through the interface.

eFlo 2.0 is built for use in harsh industrial environments.

This manual also covers configuration and control using the eFlo web interface.

Model Numbers

eFlo2.0 model numbers provide details about your eFlo device's interface type, valve type, and gas type. This is useful information to have available when contacting SSi for technical support.

Interface Type

KP= Keypad Interface
TS=Touchscreen Interface


Valve Type

A=Automatic Valve
M=Manual Valve

Gas Type

AIR – Air	H2 - Hydrogen
ARG – Argon	MULT - Multiple Gasses
C3H8 – Propane	N2 - Nitrogen
CH4 – Methane	N2O - Nitrous Oxide
CO2 - Carbon Dioxide	NAT - Natural Gas
CRS - Coarse (AutoGen Special)	NH3 - Ammonia
DA - Disassociated Ammonia	PROY - Propylene Gas (C3H6)
ENDO - Endothermic Gas	TRM - Trim (AutoGen Special)

Example:



Safety Information

Observe the following safety requirements when configuring, operating, servicing, or maintaining the eFlo instrumentation. If the device is used in a manner not specified in this manual, protection provided by the equipment may be impaired.

WARNING!

The eFlo instrument is NOT guaranteed to provide gas shutoff, nor is it designed to do so. For reliable gas shutoff, incorporate a valve that provides positive gas shutoff. Ensure that all gas flow equipment is in compliance with National Fire Protection Agency (NFPA) requirements, including those found in NFPA 86. Failure to follow these requirements could result in flammable gas leaks into the unit.

Ensure that the air and gas mixture ratio settings are within the specifications provided in this manual. Exceeding specified values could result in hazardous conditions.

Specifications

The specifications for the eFlo instrument are as follows.

Weight	10.4 lbs (4.76kg)
Power Required	24 VDC @ 750 mA
Enclosure Rating	IP10
Accuracy	4%
Repeatability	2%
Turndown Ratio	6:1
Medium Temperature Limits	-10°F to 125°F (-20°C to 51°C)
Ambient Temperature Limits	-10°F to 125°F (-20°C to 51°C)
Maximum Altitude	N/A
Flow Output Signal (Linear)	4-20mA
Maximum Output Signal Load	500Ω
Input Control Signal (Linear)	4-20mA
Communications	RS485, Ethernet, USB
Communication Protocol	Modbus RTU
Flow Meter Pressure Limits	2 psig sensors: <ul style="list-style-type: none"> • 2 psig usable limit • 4 psig overpressure limit 5 psig sensors: <ul style="list-style-type: none"> • 5 psig usable limit • 10 psig overpressure limit
<i>The installed sensors will be determined by SSI based on pressure specifications & turndown requirements.</i> <i>See the Calibration Report included with your product for more details.</i>	

Table 1 - eFlo Specifications

Installation Procedure

Installing the eFlo unit consists of a mechanical installation and an electrical installation. The mechanical installation includes mounting as well as inlet and outlet piping. The eFlo unit will be assembled prior to shipment. Before beginning installation:

- Ensure that all fittings and connections are tightly secured prior to beginning installation.
- Ensure that all expected components are present. Contact SSI at (513) 772-0060 if you have questions.

Mechanical Installation

Clearance

When installing the device, leave enough room on either side (3" is recommended) to allow users to adjust, remove and replace the existing fittings. Also ensure that the device is installed in a location that allows for easy access to the power connection.

Mounting

Proper mounting is essential for the successful operation of the eFlo instrument. Please use the mounting template (included with the eFlo unit or available at www.supersystems.com/eflo/) to ensure accuracy.

The eFlo can be supported by pipe without using the bolt holes if desired. However, if mounting in this manner, ensure that the pipe is rigid enough to support the weight of the meter.

Plumbing

The outlet openings measure 1.25" NPT. Use of bushings or reducers at these connections is acceptable as long as the smallest pipe diameter is not smaller than the installed orifice plate. See certification for that meter to determine actual orifice diameter. Contact SSI at (513) 772-0060 for questions about pipe sizing.

Thread Sealants:

Teflon or natural gas-rated pipe tape or pipe dope is acceptable for non-corrosive gases. For corrosive gases, pipe tape is not recommended, unless the manufacturer specifies that it is rated for ammonia or other corrosive gases. SSI uses and recommends Oatey, Gasiola, and X-Pando brands of pipe dope for use with corrosive gases.

NOTE: When installing the device, ensure that excessive tape or dope does not fall into the meter, as this can damage sensors, plug sensor lines, prevent flow through the meter, and prevent the device from functioning properly.

Connection Tightness:

After thread sealant is applied, tighten all connections by hand (3.5-6 turns, depending on pipe size), then use the following Turn Past Finger Tightness guide to complete the tightening process:

NPT Fitting Size	TPFT (Turns Past Finger Tightness)
1/8"	1.5-2.5
1/4"	1.5-2.5
3/8"	1.5-2.5
1/2"	1.5-2.5
3/4"	1.5-2.5
1"	1-2.5
1 1/4"	1-2.5
1 1/2"	1-2.5
2"	1-2.5

Table 2- TPFT Guide

NOTE: Never loosen a fitting for correct alignment. Doing so will prevent the thread from maintaining a proper seal.

CAUTION: Do not overtighten the connection. Overtightening can damage threads, pipes, fittings, and the eFlo device.

Leak Checking

Before operation, all plumbed components should be leak checked with a non-flammable, non-corrosive gas (air, nitrogen, argon, etc.). To avoid damage to sensors and other components, check with SSI for the maximum pressure for the sensor in your eFlo device (the installed sensor may vary based on the parameters needed in your particular application).

IMPORTANT!

Ensure that the inlet pressure is within specified parameters for your eFlo unit.

After completing the above leak check, perform another check using the gas which the eFlo is designed to measure. Leaks may occur with the designated gas that did not occur with the test gas used earlier.

Electrical Connections

Wire-In Color	Signal Type	Description
Red	+ VDC	Power Supply (24 VDC @ 750mA)
Black	- VDC	
Green / Black Stripe	+ RS485	Communications Signal Provided by Modbus Over Serial
Red / Black Stripe	- RS485	
White / Black Stripe	RLY	Normally Open Relay Contact (24 VDC)
Orange / Black Stripe	RLY	
Orange	+ mA	Analog Out - Output Flow Signal (4 - 20 mA)
Blue	- mA	
Green	+ mA	Analog In - Input Setpoint Signal (4 - 20 mA)
White	- mA	

Table 3 - Electrical Connections

Initial Network Configuration

This section is intended for use by persons familiar with Ethernet network setup.

In order to work correctly, the eFlo unit must be properly configured for the network to which it is connected.

NOTE: By default, the IP address of the eFlo unit is static, and DHCP is disabled. These settings can be adjusted through SSI's nLocateIP software (see below), the WebInterface, or through the eFlo keypad or touchscreen.

If you already know the IP address of the web interface, skip to the [Web Interface section](#). The network configuration is described in this section.

The eFlo unit will use a default IP address of 192.168.1.200. If the unit is using the default IP address, that IP address can be used to access the web interface (for more information on the web interface, refer to the [Web Interface section](#).)

The IP address of the unit can also be found by using SSI's *nLocateIP* software. This method is described below.

nLocateIP Method

Once the eFlo unit is connected to the network, you should be able to locate it on the network using SSI's *nLocateIP* software. This program is available from SSI. To use it in locating the eFlo unit on the network, follow these steps on a Windows-based PC:

1. Ensure that the eFlo unit is connected to the network.
2. Open the *nLocateIP* program.




Figure 1 - Opening nLocateIP program

3. Once the program opens, click the **Search** button. The program will begin searching for SSI devices connected to the network.




Figure 2 - Search button in nLocateIP

4. Look for text similar to the text shown at right. The corresponding IP address is the IP address that you will want to use. In the example, the IP address is 192.168.1.122.




Figure 3 - eFlo identification text in nLocateIP

Once you have found the IP address, you can configure network settings using the **Configure**

button, or complete any additional network configuration using the web interface. See the [Interface Configuration section](#).

If you are unable to find the eFlo unit in the list of devices, it is possible that a network setting (such as subnet mask) may be different, the eFlo unit may be connected to a different network, or the eFlo unit may not be powered on. Network settings can be adjusted through the eFlo keypad (see Network Configuration section below). Otherwise, SSI recommends consulting an IT engineer or network administrator. If needed, call SSI at (513) 772-0060.

Modbus Registers

The eFlo Modbus registers are as follows.

Modbus Register Number	Description
16	Actual Flow
17	Flow Sensor mA Input Value
18	Flow Setpoint
19	Decimal Place for Display of Flow and Setpoint
20	Instrument Modbus Address
21	Not Used
22	Not Used
23	Not Used
24	Not Used
25	Not Used
26	Not Used
27	Not Used
28	Air Flow
29	Not Used
30	Not Used
31	Not Used
32	Not Used
33	Not Used
34	Not Used
35	Auto (1) / Manual (0) for Control
36	Not Used
37	Reset Totalizer Values to Zero
38	Not Used
39	Totalizer Units (0 to 9999)
40	Totalizer in 10,000s (0 to 9999 -> 0 to 99,990,000)
41	Totalizer in 10,000,000s (0 to 9999 -> 0 to 999,900,000,000)

Table 4 - Modbus Registers and Descriptions

IMPORTANT!

See Appendix 3 for recommended startup procedures involving Zero Tare, Max Tare, and Altitude Adjustment. Following these procedures will provide optimal accuracy and control.

Keypad Operating Procedure

The eFlo system is equipped with a pressure and flow rate alarm (high and low), flow rate totalizer, and integrated valve control. The unit can be operated in either manual or automatic mode for flow rate control. This section of the manual provides an explanation of how the unit is operated, including: valve control modes, flow limit control, flow alarming, flow totalizing, and programming of the unit, as well as basic menu navigation.

IMPORTANT!

For best long term results, it is recommended that pressure be maintained on the flow meter at all times. Pressure can be maintained when the shut off solenoid/valve is downstream from the outlet of the meter. This will ensure long term calibration and accuracy.

Figure 4 shows the layout of the flow control panel on the Keypad eFlo 2.0 unit. An explanation of the panel's components is provided as well. The panel layout will be referenced further in this section.



Figure 4 - eFlo 2.0 LED Flow Control Panel Layout

A – LED display

By default, the LED display is used to display the current flow. The LED display can also be used to show the totalizer value, current setpoint, and Setup menu options with associated settings. During active alarms, alarm status messages may also be displayed.

B – Status indicators

These four lights come on in various situations:

Auto: When lit, the eFlo is in Auto valve control mode. When not lit, the unit is in Manual valve control mode.

Alarm: When lit, an alarm is active.

See [Alarms](#) section for more information.

Open: When lit, the valve is driving open.

Close: When lit, the valve is driving closed.

C – Totalizer button

D – Up button

E – Setpoint button

F – Return button

G – Down button


H – Select button

I – Setup button

Keypad Basic Functions


This section explains the most basic functionality of the eFlo 2.0. Additional options are available in the Setup menu and are explained in more detail in subsequent sections.

View Totalized Flow


To view totalized flow, push . Hold the button down for a few seconds to show the full totalized numeric value by scrolling left.

The flow rate totalizer records cumulative flow rates measured by the meter. The totalizer is active at all times. The maximum totalized value is 999,999,999,999 (in any unit of flow measurement).

Reset Totalized Flow

To reset the totalized flow, push and hold  for five seconds. Then push  to confirm that the value has been reset to zero.

Switch between Auto and Manual Modes


To switch between Auto and Manual modes, hold  for five seconds. When in Auto mode, the Auto light (B) will be active. When in Manual mode, the Auto light (B) will not be active.

In Auto mode, the motorized valve will be automatically adjusted based on setpoint.




Adjust Flow Rate (Manual Mode Only)

To adjust the flow rate while in Manual mode, use  and .

Display Setpoint

To display the current setpoint, press .

Adjust Setpoint

To adjust the current setpoint, press and hold  and use  and .

NOTE: Setpoint can also be adjusted using one of the following methods:

1. Remote analog signal (4-20mA)
2. Remote digital signal with Modbus serial communications over RS485 – Register 18
3. Web interface (refer to [Main Screen](#))


It is important to note that the remote analog setpoint setting overwrites any manual setting. Therefore, if manual control of setpoint is desired, ensure that there is no external signal overwriting the manual setting.

Display Alarm


When an alarm is active, the Alarm light will turn on. A warning message will be displayed on the LED screen as shown. Setpoints for these alarms are set through a Modbus interface or by using the eFlo Web Interface. See [Alarms](#) section for more information.

LED Display	Alarm
LoPr	Low Pressure
HiPr	High Pressure
LoFL	Low Flow
HiFL	High Flow

Enter Menu

To enter the Setup menu, hold  for five seconds.

Keypad Setup Menu System

To enter the Setup menu, hold  for five seconds.

Setup Menu Keypad Functions

When you first enter the setup menu, the eFlo will display **P 100** (the current menu option).








To navigate the setup menu, use  and  to move vertically through the menu options, and use  and  to move horizontally through the menu options. (Think of  and  as your Right and Left buttons while navigating the menus (see Figure 5 - Visualization of Menu Navigation Functions).



Figure 5 - Visualization of Menu Navigation Functions

Once you have reached the desired menu option, press  to access that option. See Figure 6 - Keypad Menu Navigation Menu for a map of the menu options. The options are described in more detail in the Menu System Details section.










Figure 6 - Keypad Menu Navigation Menu

EXAMPLE –To access the “Low Pressure Alarm Limit” option (P3.30):



- Hold  for five seconds. You will enter the menu at P 100.
- Press  twice to move (vertically) to P300
- Press  to move (horizontally) to P3.10
- Press  twice to move (vertically) to P3.30
- Press  to enter into the menu option.

Once you have entered into a menu option, use  and  to cycle through options or set values.

When ready to save the current setting or value, press .

To exit the menu option without saving changes, press .

Exiting the Menu System

To exit the menu system entirely, press  to return to the 100-level menus, then press  again to return to the default eFlo display.

Menu System Details

P 100: Process Variable – These values are read-only and are meant for diagnostic purposes.

- **P 110: Inlet Pressure** – Line Pressure measured by the high pressure sensor; the value is based on the unit set in **P220**.
- **P 120: Gas Temperature** – Line Temperature; the value is based on the unit set in **P230**
- **P 130: Differential Pressure** – Difference in pressure measured between the high and low pressure sensors; the value is based on the unit set in **P220**

P200: Process Options – These values are modifiable and change how the user views the flow rate and process variables. Refer to Appendix 4 for an explanation of the various display options.

- **P210: Flow Units** – Unit of flow rate displayed
- **P220: Pressure Units** – Unit of pressure displayed
- **P230: Temperature Units** – Unit of temperature displayed
- **P240: Display Average** – Increasing this value will increase the average of the flow rate being displayed on the main screen (range for this value is 1 to 255)

P300: User Alarms – Values are modifiable and allow the user to set custom high and low flow alarms as well as low pressure alarms in addition to the factory low and high pressure alarms

- **P310: Low Flow Alarm Limit** – Sets the low flow alarm limit (0=alarm not set)
- **P320: High Flow Alarm Limit** – Sets the high flow alarm limit (0=alarm not set)
- **P330: Low Pressure Alarm Limit** – Sets the low pressure alarm limit (0=alarm not set)

NOTE: *Factory low and high pressure alarms are not viewable or editable*

P400: Serial Communications – Values are modifiable and are used to set the serial communications. Refer to Appendix 4 for an explanation of the various display options.

- **P410: Baud Rate**
- **P420: Address**
- **P430: Parity Bits**

P500: Ethernet Communications – Values are modifiable and are used to set the Ethernet Settings. Refer to Appendix 4 for an explanation of the various display options.

- **P510: DHCP** – Enabling allows the unit to automatically obtain addressing
- **P520: IP Octet** – Used to manually set the IP address of the device
- **P530: Subnet** – Used to manually set the Subnet of the device
- **P540: Gateway** – Used to manually set the Gateway of the device

P6.00: Setup – Values are modifiable and changes important device options. Refer to Appendix 4 for an explanation of the various display options.

NOTE: *These options should ONLY be changed if absolutely necessary. Please contact SSi before making changes to these settings.*

- **P6.10: Zero Tare** – Resets the zero flow rate of the meter (manual mode with valve closed only)
- **P6.20: Analog Max Flow** – Sets the 4-20mA analog in and out based on desired max flow rate allowable
- **P6.30: Control Mode** – Sets control method between flow rate and valve position
- **P6.40: Gas Type** – Used to set the gas type of the meter **NOTE: changing this value may limit the amount of flow indicated by the info tag on the front of the meter**
- **P6.50: Max Valve Position Tare** – Sets the max position the valve is capable of driving to in valve position mode. (manual mode with valve opened to desired max flow rate)
- **P6.60: Altitude Compensation** – Sets the altitude for the installed location.

Reference [Appendix 1: Menu Option Tables](#) for a detailed chart of parameter options


Touchscreen Operating Procedure

The eFlo system is equipped with a pressure and flow rate alarm (high and low), flow rate totalizer, and integrated valve control. The unit can be operated in either manual or automatic mode for flow rate control. This section of the manual provides an explanation of how the unit is operated, including: valve control modes, flow limit control, flow alarming, flow totalizing, and programming of the unit, as well as basic menu navigation.

IMPORTANT!

For best long term results, it is recommended that pressure be maintained on the flow meter at all times. Pressure can be maintained when the shut off solenoid/valve is downstream from the outlet of the meter. This will ensure long term calibration and accuracy.



Figure 4 shows the layout of the main screen on the Touchscreen eFlo 2.0 unit.





Touchscreen Basic Functions

This section explains the most basic functionality of the eFlo 2.0. Additional options are available in the Setup menu and are explained in more detail in subsequent sections.

View Totalized Flow


To view totalized flow, push . This will bring up the totalizer screen. To return to the main screen, press .

Reset Totalized Flow

To reset the totalized flow, push  from the totalizer screen. To return to the main screen, press .

The flow rate totalizer records cumulative flow rates measured by the meter. The totalizer is active at all times. The maximum totalized value is 999,999,999,999 (in any unit of flow measurement).

Switch between Auto and Manual Modes

To switch between Auto and Manual modes, hold  for five seconds. When in Auto mode, the screen will display a yellow background (see below)

In Auto mode, the motorized valve will be automatically adjusted based on setpoint.








Figure 8 - Auto and Manual Modes

Adjust Flow Rate (Manual Mode Only)

To adjust the flow rate while in Manual mode, use  and .

Adjust Setpoint

To display the current setpoint, press . This will bring up the setpoint screen.


Use the numeric keypad to enter the desired setpoint. Press  to accept changes, or press  to return to the main screen without saving changes.

NOTE: Setpoint can also be adjusted using one of the following methods:

1. Remote analog signal (4-20mA)
2. Remote digital signal with Modbus serial communications over RS485 – Register 18
3. Web interface (refer to Main Screen).

It is important to note that the remote setpoint setting overwrites any manual setting. Therefore, if manual control of setpoint is desired, ensure that there is no external signal overwriting the manual setting.

Enter Menu

To enter the Setup menus, press .

The Setup menu contains seven options:




Figure 9 - Setpoint Screen



Process Variable Menu

These values are read-only and are meant for diagnostic purposes.





Figure 10 –
Process Variable Menu

Press  to return to the menu screen.



Units Menu

These values are modifiable and change how the user views the flow rate and process variables. By default, this menu is passcode-protected. Use the numeric keypad to enter the appropriate security code.






Figure 11 - Units Menu

Flow Units – Unit of flow rate displayed

Temperature Units – Unit of temperature displayed


Pressure Units – Unit of pressure displayed



Tap the desired units for each parameter. Press  to accept changes, or press  to return to the menu screen without saving changes.



Gas Menu

By default, this menu is passcode-protected. Use the numeric keypad to enter the appropriate security code.



Tap the desired gas type. Press  to accept changes, or press  to return to the menu screen without saving changes.

NOTE: changing this value may limit the amount of flow indicated by the info tag on the front of the meter


This option should ONLY be changed if absolutely necessary. Please contact SSI before making changes to this setting.

Figure 12 - Gas Menu





Time Menu

By default, this menu is passcode-protected. Use the numeric keypad to enter the appropriate security code.



Use the numeric keypad to set the date and time of the device.

Use  to clear the current selection, and use  to advance to the next input box.



Press  to accept changes, or press  to return to the menu screen without saving changes.

Figure 13 - Time Menu



Ethernet Communications Menu

By default, this menu is passcode-protected. Use the numeric keypad to enter the appropriate security code.

Values are modifiable and are used to set the Ethernet Settings.



Use the numeric keypad to input the desired settings.

IP 1-4 – Used to manually set the IP address of the device

MA 1-4 – Used to manually set the Subnet mask of the device

GW 1-4 – Used to manually set the Gateway of the device

DHCP – Enabling allows the unit to automatically obtain addressing

Use  to clear the current selection, and use  to advance to the next input box.



Press  to accept changes, or press  to return to the menu screen without saving changes.

Figure 14 - Ethernet Communications Menu



Serial Communications Menu

Values are modifiable and are used to set the serial communications.

Baud Rate – Used to select the desired Baud Rate. Tap to select.

Modbus Address - Use the numeric keypad to input the desired settings.



Press  to accept changes, or press  to return to the menu screen without saving changes.

Figure 15 - Serial Communications Menu



Flow Alarm Menu




Figure 16 - Flow Alarm Menu

Display Average – Increasing this value will increase the average of the flow rate being displayed on the main screen (range for this value is 1 to 255)

Max Flow – Sets the 4-20mA analog in and out based on desired max flow rate allowable

Low Flow Alarm Limit – Sets the low flow alarm limit (0=alarm not set)

High Flow Alarm Limit – Sets the high flow alarm limit (0=alarm not set)

Control Mode – Sets control method between flow rate and valve position.

Maintenance

There is no routine maintenance required for the eFlo 2.0 unit. Please contact SSi with any questions not covered in the Troubleshooting Guide.

Web Interface

The eFlo meter is equipped with a web interface that can be accessed using an Internet web browser such as Mozilla Firefox, Google Chrome, or Microsoft Internet Explorer.

In order to open the web interface with a web browser, you will need to know either the IP address or the hostname of the web interface. SSi recommends asking an IT engineer or network administrator to set up the web interface prior to use.

Using the Web Interface

To access the web interface, open a web browser, and in the location bar, enter the IP address or name of the webserver. The main screen will then appear, as shown in Figure 7.




Figure 17 - Main Screen of Web Interface

The web interface features several screens. Note that some screens require a login and password. The default login is username **admin** with password **2** (unless otherwise specified by the customer at the time of order).


- **Main.** This screen shows status information such as flow rate, setpoint, and which LEDs are illuminated on the unit, and the amount of total flow since the previous reset.
- **Instrument Information.** This screen shows eFlo model number, unit serial number, and software version number.
- **Diagnostics.** This screen displays information on pressure differential, inlet pressure, temperature, and density.
- **Basic Configuration.** The Basic Configuration screen displays, and allows you to change, basic operating parameters for the eFlo unit.
- **Instrument Configuration** (login and password required). The Instrument Configuration screen displays, and allows you to change, operating parameters for the eFlo unit.
- **Network Configuration** (login and password required). Using this screen, you can adjust network settings, such as host name and IP address. Note that if DHCP is enabled

Main Screen

The main screen (shown above) provides real-time information on the operation of the eFlo unit. The current gas flow process value and setpoint are displayed, as well as the totalized flow. Four circular icons on the screen represent the four LEDs on the front of the unit; these icons will illuminate and darken along with the corresponding LEDs. The **Open** button will drive the motor to open the valve, and the **Close** button will drive the motor to close the valve.

Instrument Information

The Instrument Information page displays the SSI model number, specific serial number of the eFlo unit, and the current version of the software.




Tue Apr 17 2018, 6:55:56 AM		Super Systems Web Interface	
Main	Model #	eFlo 2.0	
Instrument Information	Main Version #	1.02	
Diagnostics	Main Serial #	EF16001	
Basic Configuration	Web Version #	1.01	
Instrument Configuration			
Network Configuration			

Copyright © 2017 Super Systems, Inc.

Figure 18 - Instrument Information Web Page

Diagnostics

This screen displays information on pressure differential, inlet pressure, temperature, and density.




Tue Apr 17 2018, 6:59:15 AM		Super Systems Web Interface	
Main	Differential:	0.0 PSI	
Instrument Information	Inlet:	1.0 PSI	
Diagnostics	Temperature:	77.0 °F	
Basic Configuration	Density:	0.000 kg/m³	
Instrument Configuration			
Network Configuration			

Copyright © 2017 Super Systems, Inc.

19 - Diagnostics Web Page

Basic Configuration

The Basic Configuration page displays current basic parameter values and provides the ability to set, select, and reset values. The parameters are described in more detail below.



SuperSystems

Tue Apr 17 2018, 7:01:09 AM Super Systems Web Interface

Field	Input	Submit	Current
RTCC		Set Val	
Setpoint	0.00	Set Val	0.00
Address	10	Set Val	10
Baud Rate	28.8k ▼	Select	28.8k
Serial	8E1 ▼	Select	8E1
Reset Total		Reset	
Tare		Tare	
Max Tare		Max Tare	
Low Flow Alarm	0.00	Set Val	0.00
High Flow Alarm	0.00	Set Val	0.00
Low Pres Alarm	0.00	Set Val	0.00

Copyright © 2017 Super Systems, Inc.


Figure 20 - Basic Configuration Web Page

Parameter	Description
RTCC	Sets the date/time (real time calendar clock)
Setpoint	The current flow setpoint
Address	The Modbus address of the device - a number from 1-247. The device will respond to 250 universally.
Baud Rate	The baud rate for communications.
Serial	The serial port parameter setting.
Reset Total	Resets the totalized value
Tare	Resets the zero flow rate of the meter (manual mode only)
Max Tare	Sets the max position the valve is capable of driving to
Low Flow Alarm	Sets the low flow alarm limit (0=alarm not set)
High Flow Alarm	Sets the high flow alarm limit (0=alarm not set)
Low Pres Alarm	Sets the low pressure alarm limit (0=alarm not set)

Table 5 - Parameters and Descriptions for Basic Configuration

Instrument Configuration

The Instrument Configuration page displays current parameter values and provides the ability to set, select, and reset values. The parameters are described in more detail below.



SuperSystems

Tue Apr 17 2018, 7:16:20 AM Super Systems Web Interface

Field	Input	Submit	Current
Gas Type	Air ▼	Select	Air
Flow Units	kg/hr ▼	Select	kg/hr
Pres. Units	PSI ▼	Select	PSI
Temp. Units	°F ▼	Select	°F
Sensor Ave.	240	Set Val	240
Max Flow	6.32	Set Val	6.32
Ctrl Mode	Flow ▼	Select	Flow


Copyright © 2017 Super Systems, Inc.

Figure 21 - Instrument Configuration Web Page

Parameter	Description
Gas Type	Used to set the gas type of the meter <i>NOTE: changing this value may limit the amount of flow indicated by the info tag on the front of the meter</i>
Flow Units	Unit of Flow Rate displayed
Pres. Units	Unit of Pressure displayed
Temp. Units	Unit of Temperature displayed
Sensor Ave.	Increasing this value will increase the average of the flow rate being displayed on the main screen (range for this value is 1 to 255)
Max Flow	Sets the 4-20mA analog in and out based on desired max flow rate allowable
Ctrl Mode	Sets the control mode between flow rate and valve position

Table 6 - Parameters and Descriptions for Instrument Configuration

Interface Configuration



SuperSystems

Tue Apr 17 2018, 7:24:32 AM Super Systems Web Interface

Main

Instrument Information

Diagnostics

Basic Configuration

Instrument Configuration

Network Configuration

Interface Configuration

This page allows the configuration of the board's network settings.

CAUTION: Incorrect settings may cause the board to lose network connectivity. Recovery options will be provided on the next page.

Enter the new settings for the network interface below:

MAC Address:	54:10:ec:83:d9:0b
Host Name:	MCHPBOARD_E
<input type="checkbox"/> Enable DHCP	
IP Address:	192.168.1.202
Gateway:	192.168.7.254
Subnet Mask:	255.255.248.0
Primary DNS:	192.168.1.1
Secondary DNS:	0.0.0.0
<input type="button" value="Restart Interface"/>	

Copyright © 2017 Super Systems, Inc.

Figure 22–Interface Configuration Web Page

The Interface Configuration page allows you to view network settings and change certain settings as well. SSi recommends consulting an IT engineer or network administrator before changing any of these settings.

The first two fields on the page show the MAC address and Host Name. The MAC address should not be changed. The Host Name can be changed as needed.

To enable dynamic assignment of IP addresses, click on the **Enable DHCP** checkbox. Dynamic assignment means that the eFlo unit's IP address on the network will be assigned automatically, preventing IP address conflicts. The network must support dynamic IP assignment in order for this to work.

If Enable DHCP is not checked, IP and other settings can be changed manually. These settings should be verified with your network administrator before being changed. Failure to do so could result in IP conflicts and other network issues.

Alarms

Alarm Code	Possible Causes	Possible Corrective Actions
LoPr - Low Pressure	<p>Activated when low pressure has been indicated based on either factory or user specified values</p> <p><i>*factory values are not editable and cannot be deactivated; call SSI with any questions</i></p>	<p>Increase regulator pressure</p> <p>Verify all upstream solenoids and/or ball valves are open</p> <p><i>*make sure not to exceed pressure limits for the sensors indicated on page 6</i></p>
HiPr - High Pressure	<p>Activated when high pressure has been indicated based on either factory or user specified values</p> <p>If indicated pressure is above the range of the sensor, the meter WILL NOT show accurate values</p> <p><i>*factory values are not editable and cannot be deactivated; call SSI with any questions</i></p>	<p>Decrease regulator pressure below the usable range of the sensors</p> <p><i>*make sure not to exceed pressure limits for the sensors indicated on page 6</i></p>
LoFL - Low Flow	<p>Activated when low flow has been indicated based on user specified values</p>	<p>Increase flow rate on meter to a value above what has been set</p> <p>It is possible that low pressure is limiting the flow rate and pressure should be increased</p> <p>It is also possible that high pressure has been achieved and the meter is now reading incorrectly</p>
HiFL - High Flow	<p>Activated when high flow has been indicated based on user specified values</p>	<p>Increase flow rate on meter to a value above what has been set</p> <p>It is possible that low pressure is limiting the flow rate and pressure should be increased</p>

Table 7 - Alarms

If you experience problems and cannot find the solution after troubleshooting, please call SSI Technical Support at (513) 772-0060.

Warranty

Limited Warranty for Super Systems Products:

The Limited Warranty applies to new Super Systems Inc. (SSI) products purchased direct from SSI or from an authorized SSI dealer by the original purchaser for normal use. SSI warrants that a covered product is free from defects in materials and workmanship, with the exceptions stated below.

The limited warranty does not cover damage resulting from commercial use, misuse, accident, modification or alteration to hardware or software, tampering, unsuitable physical or operating environment beyond product specifications, improper maintenance, or failure caused by a product for which SSI is not responsible. There is no warranty of uninterrupted or error-free operation. There is no warranty for loss of data—you must regularly back up the data stored on your product to a separate storage product. There is no warranty for product with removed or altered identification labels. SSI DOES NOT PROVIDE ANY OTHER WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OF IMPLIED WARRANTIES, SO THIS LIMITATION MAY NOT APPLY TO YOU. SSI is not responsible for returning to you product which is not covered by this limited warranty.

If you are having trouble with a product, before seeking limited warranty service, first follow the troubleshooting procedures that SSI or your authorized SSI dealer provides.

SSI will replace the PRODUCT with a functionally equivalent replacement product, transportation prepaid after PRODUCT has been returned to SSI for testing and evaluation. SSI may replace your product with a product that was previously used, repaired and tested to meet SSI specifications. You receive title to the replaced product at delivery to carrier at SSI shipping point. You are responsible for importation of the replaced product, if applicable. SSI will not return the original product to you; therefore, you are responsible for moving data to another media before returning to SSI, if applicable. Data Recovery is not covered under this warranty and is not part of the warranty returns process. SSI warrants that the replaced products are covered for the remainder of the original product warranty or 90 days, whichever is greater.

Revision History

Rev.	Description	Date	MCO #
-	First release	5/24/2018	2234
A	Additional Flow and Pressure Units. Updated Keypad information. Updated navigation map for LED model, added Altitude Compensation description, added startup procedure Appendix, added miscellaneous conditions information and IP information	2/21/2019	2256
B	Added model number information	5/3/2019	2265

Appendix 1: Menu Option Tables

Table 1		Table 5		Table 9	
Value	Flow Units	Value	Parity Option	Value	Gas Type
cFh	CFH	8N1	8N1	c2h8	Acetylene
m3h	m³/h	8E1	8E1	Air	Air
LPh	l/hr	8N2	8N2	nh3	Ammonia
GPh	gph			Ar	Argon
cFm	CFM			co2	Carbon Dioxide
m3m	m³/min			co	Carbon Monoxide
LPm	l/min			dA	Dissociated Ammonia
GPM	gpm			Endn	Endo (w/methane)
Lb/h	lb/h			EndP	Endo (w/propane)
KGh	kg/h			hE	Helium
				h2	Hydrogen
Table 2				ch4	Methane
Value	Pressure Units			nG	Natural Gas
inH2O	inH ₂ O			n2O	Nitrogen
PSI	PSI			n2O	Nitrous Oxide
OSI	OSI			o2	Oxygen
mBar	mBar			c3h8	Propane
kPa	kPa			c3h6	Propylene
mmHg	mmHg				
mmH2O	mmH ₂ O			Table 10	
				Value	Alarms
Table 3				LoPr	Low Pressure
Value	Temperature Units			HiPr	High Pressure
F	F			LoFL	Low Flow
C	C			HiFL	High Flow
Table 4		Table 8			
Value	Baud Rate	Value	Control Mode		
1200	1200	0	Flow Control		
2400	2400	1	Valve Position		
4800	4800				
9600	9600				
144	14400				
192	19200				
288	28800				
384	38400				
576	57600				
768	76800				
1152	115200				

Appendix 2: Verification Procedures

Calibration Verification

The following procedure should be used for verifying the calibration of the flow meter

Items needed

- Calibrated Manometer with a usable range of 0 – 27.7 "wcg (0 – 1 PSI)
- Certificate of Calibration for the meter being verified

Procedure

1. Connect the high and low pressure ports of the manometer to the high and low pressure ports of the flow meter with the necessary tubing. Open the ball valves
2. Using the Verification Data section of the Certificate of Calibration, enter a flow setpoint based on the points given
3. Once setpoint has been achieved, verify the differential pressure on the manometer is within the tolerance indicated for that point in the Verification Data section
 - a. *If the differential pressure reading is out of tolerance, verify the pressure and temperature values match the values listed under the "Calibration Condition" section of the "Certificate of Calibration". If the values are different, you will need to use the equation given on the cert, along with the actual pressure and temperature readings to obtain new differential pressure points. These values can be found in the keypad in the setup menu under the P1.10 & P1.20 parameters or in the touchscreen Process Variable Menu.*
4. Once the verification is complete, close the high and low pressure port ball valves and remove the manometer and tubing
5. If the meter is determined to be out of tolerance, continue to the "Sensor Accuracy Verification" section of the manual
6. If the sensors are determined to be within tolerance but the flow rates are not, the meter may need to be recalibrated by SSI if necessary. Please contact SSI for next steps.

Sensor Accuracy Verification

The following procedure should be used for verifying the accuracy of the installed pressure sensors

Items needed

- Calibrated Manometer with a usable range of 0 – 27.7 "wcg (0 – 1 PSI)

Procedure

1. Connect the high and low pressure ports of the manometer to the high and low pressure ports of the flow meter with the necessary tubing and open the ball valves

2. Go to the "Process Variables" section of the setup menu and check the indicated differential pressure reading. This is found in the P1.30 parameter of the keypad or the Process Variable menu of the touchscreen.
3. The differential pressure reading on the flow meter should be +/- 4% full scale of the compared reading of the manometer
 - a. *Example: a full scale reading of 12"wcg should be +/- 0.48"wcg*
4. If the sensors are determined to be out of tolerance, the sensors may need to be replaced. Please contact SSI for next steps.

Appendix 3: Startup Procedures

For optimal accuracy and control, the following procedure is recommended:

LED model:

1. **Zero Tare** (Resets the zero flow rate of the meter)
 - a. With the meter in manual mode, drive the valve completely closed.
 - b. Enter the setup menu and enter **P6.10**
 - c. Change the value to 1 and press Select to save.
2. **Max Tare** (Sets the max position the valve can drive to in valve position mode)
 - a. With the meter in manual mode, drive the valve open to the desired max flow rate.
 - b. Enter the setup menu and enter **P6.50**
 - c. Change the value to 1 and press Select to save.
3. **Altitude Compensation**
 - a. Enter the setup menu and enter **P6.60**
 - b. Enter the actual altitude for the installed location.
 - c. Press Select to save.

Touchscreen model: